

SOLID SURFACE

WASHBASIN

Installation

Care

Maintenance and Warranty



Head Office Address: Offices No. 2408-2508, Building 5A, Longguang Jiuzuan, Longhua District,

Fax: 0086-755-82875921

☎ Phone: 0086-755-82875700



Pre-Installation Checks

Read these guidelines before starting installation.

Installation must be carried out by a professional.

Safety Measures

Ask for help when handling heavy objects.

Use personal protective equipment.

Product Inspection

Check the items upon receipt.

Report any problem within 7 days of delivery.

Installing damaged or incorrect items will invalidate the warranty.

Required Tools

Spirit level

Electric drill

Bathroom silicone

Specific Installation Instructions

proper fit and correct plumbing installation.

Thoroughly check all items as soon as they are delivered.

If you detect any faults, damage or discrepancies with the item, get in touch with the retailer where you made the purchase immediately.



IMPORTANTE:

Do not begin installation if you detect any problem.

Preparation Phase

1. Surface Preparation:

First, clean and dry the countertop surface. Confirm that the cutout

matches the product. See Figure 2 in the installation manual for guidance.

Fit Test

2. Positioning the Washbasin:

plumbing components, including faucets, to check for potential interference that could hinder installation or cause damage to the product or cabinet. Once everything fits correctly, remove the plumbing components and prepare for final installation.

Measuring and Positioning

3. Determining the Washbasin Location:

Measure the water outlet on the wall to determine the exact location (vertical and specific and the product's plumbing details.

Adhesive Application

4. Applying Sealant:

Place the washbasin upside down on a clean protective blanket. Apply a continuous, neat and generous bead of silicone adhesive sealant around the edge that will come into contact with the countertop. Note that the application process may vary between countertop and semi-recessed washbasins. See Figure 1 for detailed instructions.

Installation

Carefully lift and place the washbasin onto the cabinet, making sure that the drain lines up with the cutout. It is crucial to establish a watertight seal between the washbasin and the countertop.

Important Notice:

product's instructions.

Drain Installation

6. Fitting the Drain:

Insert the drain into the washbasin, making sure all seals are positioned correctly, then tighten the nut to secure the drain firmly in place. See Figure 4 for visual guidance.

Plumbing Connection

7. Connecting Plumbing Components:

Reconnect and secure all plumbing components, making sure they are properly and firmly tightened.

Leak Test


8. Leak Test:

Close the pop-up drain and fill the washbasin with water to check for leaks.


let the water flow and check again to make sure all components are well sealed and there are no leaks.

Preparation

First, properly prepare the installation accessories and tools needed.



Tape measure Spirit level Silicone



Pencil Screwdriver Drill 35/64" drill bit

Countertop Washbasin Installation Guide

1. Measure and position the washbasin. Install the faucet and drain fittings (not included) according to the manufacturer's instructions. Measure the outer perimeter of the drain opening and mark the countertop. (Figure 4)
Temporarily place the washbasin on the countertop to check the fit. (Figure 1)

2. Cut the countertop for the drain opening

Cut or drill the drain opening in the countertop using the appropriate drill bit, following the Drain opening cut line as illustrated. (Figure 2)




Figure 1 Adaptor Figure 4 35/64" drill bit

Hole outline of the drain



Figure 2 5. Finishing

3. Apply silicone for extra stability

Apply silicone sealant around the lower edge of the washbasin and the drain outlet. Clean off excess silicone around the washbasin. (Figure 3)





Figure 3

4. Install the drain fittings and faucet



Finish the faucet and drain connections, run water in the washbasin and check for leaks. (Figure 5)




Figure 5

Habitat One

Maintenance Guidelines and Warranty Information

Solid Surface Care

bathtubs and kitchen countertops, are made from high-quality acrylic resin, designed for kitchen and bathroom environments. To ensure durability and maintain the aesthetic appeal of these solid surfaces, regular

Daily Cleaning

? Basic Cleaning: Clean up spills immediately with mild detergent or soapy water, using a soft sponge or non-scratch squeegee.

? Deep Cleaning: To remove tougher stains, use a mild abrasive detergent diluted and applied with a soft cloth, moving in circles. For persistent stains, use a non-scratch squeegee with the detergent.

? Intensive Cleaning/Repair: For extreme stains or light scratches, lightly sand the surface with fine-grit sandpaper/glass paper.

? Basic Cleaning for Soft-touch Surfaces (Softskin): Use warm soapy water or mild detergent with a soft cloth, rinse and dry with a towel.

Preventive Measures

up to 360 °F (182 °C). Although brief contact with hot pots is tolerable, prolonged heat exposure should be avoided. Let cookware cool down before placing it on the surface.

? Avoiding Damage: Do not use strongly acidic or alkaline detergents, as they may damage the surface. For drain cleaners, make sure they do not come into contact with the surface, and use them according to the

product's
instructions.

Restoration

If the solid surface gets scratches or small chips from sharp objects, these can be fixed with sanding techniques:

? Light Scratches: Use a sanding sponge for light abrasions.

? Deep Scratches or Chips: Start with coarse 100 or 150 grit sandpaper and gradually move to finer grits to restore smoothness and the original finish.

Quality Commitment

10-year warranty.

? Warranty against manufacturing and material defects under normal use and normal maintenance.

Warranty Exclusions

1. Accidents, abuse or misuse.
2. Damage caused by excessive heat.
3. Breakage not related to manufacturing.
4. Improper care and maintenance.
5. Unauthorised modifications or repairs.
6. Defects in the customer's own design.

Warranty Duration and Scope

? 10-year warranty from the date of delivery.

? Supersedes other warranties, express or implied.

offer this warranty.

Warranty Service

? Liability is limited to repair or replacement within the

Repair Limitations

unauthorised personnel.

? All repairs require the company's written authorisation.

Warranty Claims and Support

warranty claims, as detailed on your invoice.